


Anziehvorschrift für Zylinderkopf		425.170		Das Original
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
				
802.661 M 12x1,5x147				
Anziehen/ Tightening/ Serrage/ Apriete	* 80 Nm □ 50 Nm ➤ 90° ➤ 90° ★ 25 min ➤ 90°			
Zeichenerklärung / Explanations / Explication / Explicacion				
* □ ★ ● ➤	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Mot. M41 D18				
E36 318tds				
1,87 mm $\frac{1}{16}$				
3 Löcher / Holes / Trous				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*425.170*		