


Anziehvorschrift für Zylinderkopf		704.620		
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Honda		
Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		Das Original		
				
Anziehen/ Tightening/ Serrage/ Apriete		* 30 Nm 68 Nm		
Zeichenerklärung / Explanations / Explication / Explicacion				
	neue Zylinderkopf-schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
	Setzzeit	relaxation time	durée de tassement	tiempo de espera
	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
82 mm Ø				
Mot. B20A3 OHC, 1958 ccm, 81 kW (110 PS)				
B20A5 DOHC, 1958 ccm, 110 kW (150 PS)				
Prelude 2,0 1987>1992				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*704.620*	