


Cylinder Head Tightening Instructions

HG720



	1	2	3	4	5	6
Reference	HG718	HG719	HG720			
Piston	0.50-0.60	0.61-0.70	0.71-0.80			

Headbolt Tightening Sequence



Fitment Procedure

	Stage 1	Stage 2	Stage 3	Stage 4	Stage 5	Stage 6	Stage 7	Stage 8	Retighten?
Botl Type 1									
Kilos	2 Kpm	4 Kpm	-90°+4 Kpm	+60°	+20°				
Pounds	15 lbft	29 lbft	-90°+29 lbft	+60°	+20°				
Newton M's	19.6 Nm	39.2 Nm	-90°+39.2 Nm	+60°	+20°				
Botl Type 2									
Kilos									
Pounds									
Newton M's									
Botl Type 3									
Kilos									
Pounds									
Newton M's									
Botl Type 4									
Kilos									
Pounds									
Newton M's									

Fitment Key	Description of Required Procedure
-/+ X°	Loosen or tighten the head bolt by the 'X'-value specified in the stage. Follow indicated tightening order.
↔	Run the engine until it reaches working temperature. Let the engine cool with the bonnet open for a minimum of four hours. Remove the expansion tank cap. Should retightening be required, loosen by 90° and then retighten observing the tightening procedure above.
Retighten?	If required, should be performed between 620-930 Miles (1000-1500 Km).