



INSTALLATION MANUAL

A-3303 Arnott New Rear Air Spring Fiat Scudo, Peugeot Expert, Citroën Jumpy



Engineered to Ride, Built to Last®

CONGRATULATIONS ON YOUR PURCHASE OF AN ARNOTT® SUSPENSION PRODUCT

WE AT ARNOTT LLC ARE PROUD TO OFFER A HIGH QUALITY PRODUCT WITH ALL THE TECHNICAL SUPPORT YOU NEED. THANK YOU FOR YOUR CONFIDENCE IN US AND OUR PRODUCT.

Proper installation is essential to experience and appreciate the benefits of this system. Please take a moment to review these installation instructions before you begin to install these components on your vehicle. The removal and installation of air suspension products should only be performed by a fully qualified and certified automotive professional.

It is equally important to be aware of all necessary safety measures while installing your new Air Suspension System. This includes proper lifting and immobilizing of the vehicle and isolation of any stored energy to prevent personal injury or property damage.

GENERAL INFORMATION

Reading this manual signifies your agreement to the terms of the general release, waiver of liability, and hold harmless agreement, the full text of which is available at www.arnottinc.com and www.arnotteurope.com.



WARNING:

The air suspension system is under pressure (up to 10 bar, or 150 lbf/in). Verify pressure has been relieved and disconnect power to the air suspension system prior to disassembly. Do not allow dirt or grease to enter the system. Always wear standard hand, ear, and eye protection when servicing the air suspension system.

- Not to be stored below 5°F (-15°C) and above 122°F (50°C).
- Avoid damage to air lines and cables.
- Removal and installation is only to be performed by fully qualified personnel.
- Use car manufacturer's diagnostic software.

CAUTION:

Damage to the vehicle and air suspension system can be incurred if work is carried out in a manner other than specified in the instructions or in a different sequence.

To avoid the possibility of short circuits while working with electric components consult your owner's manual on how to disconnect your battery.

Consult your vehicle owner's manual, service manual, or car dealer for the correct jacking points on your vehicle and for additional care, safety and maintenance instructions. Under no circumstances should any work be completed underneath the vehicle if it is not adequately supported, as serious injuries and death can occur.

For vehicles with a "Closed Air Supply System," replacement of components requires proper adherence to procedures set forth within OE servicing literature. Failure to comply with the OE prescribed procedures can result in component damage and/or failure.

AIR SPRING REMOVAL

1. Raise the vehicle.
2. Deflate the applicable air spring using a diagnostic scan tool.
3. Disconnect the air line from the air spring by pushing the collet on the fitting inward and pulling the air line out. (Figure 1)




FIGURE 1

4. Gently push the lower piston upward and rotate the air spring a quarter turn to remove the air spring from the vehicle. (Figures 2, 3)



FIGURE 2



FIGURE 3

5. Removal complete.

AIR SPRING INSTALLATION



WARNING:

Tighten all nuts and bolts to manufacturer's specifications during the installation process.
Install the new Arnott air spring in its delivered, compressed state.

1. Install the new Arnott air spring by positioning the upper mount and rotating the spring a quarter turn. (Figure 4) Then guide the lower piston into its seat on the control arm. (Figure 5)



FIGURE 4



FIGURE 5

2. Remove the shipping pin from the air spring. (Figure 6)




FIGURE 6

3. Insert the air line into the spring. (Figure 7)



FIGURE 7

4. Slowly lower the car until the lower piston is fully seated on the control arm. (Figure 8)



FIGURE 8

5. Use a diagnostic scan tool to inflate the air spring, ensuring the top and bottom mounts are properly seated. (Figure 9)



FIGURE 9

6. Lower the vehicle completely.
7. Installation complete.

Arnott®

Suspension Products

Arnott US Business Office:

www.arnottinc.com

100 Sea Ray Drive
Merritt Island, FL 32953

Call: 800.251.8993

321.868.3016

Fax: 321.868.3703

Email: techassistance@arnottinc.com

Arnott Europe Business Office:

www.arnotteurope.com

Industrieweg 19
5145 PD, Waalwijk (NL)

NL Phone: +31 73 7850 580

DE Phone: +31 85 2087 438


UK Phone: +44 203 3186 124

BE Phone: +32 258 846 90


ES Phone: +34 91 901 10 56

FR Phone: +32 78 48 46 93


Email: info@arnotteurope.com




Air Springs




Struts




Shocks




Compressors




Dryers



Coil Spring
Conversion Kits



Valve Blocks



Ride Height
Sensors