



# VKJML 01001

Product Information - February 2015



Passenger Cars and Light Commercial Vehicles



Technical information: **VKJML 01001**



VKJML 01001 is a set of 12 loose clamps contained into a plastic bag, suitable to tighten the small diameter of all specific rubber boot kits, Universal or Semi-universal boot kits, but not thermoplastic ones.



For a professional repair when tightening the clamps, it is recommended to use the SKF tool VKN 400. Incorrect tightening of the clamps can cause premature failure of the CV-Joint!



Clamp dimensions:

- Length: 250 mm
- Width: 5 mm



Tightening tool: **VKN 400**

## VKJML 01001 Applicable kits

SKF Universal boot kit	SKF Semi-Universal boot kit		
VKJP 01000	VKJP 01010	VKJP 01015	VKJP 01020
VKJP 01001	VKJP 01011	VKJP 01016	VKJP 01021
VKJP 01003	VKJP 01012	VKJP 01017	VKJP 01022
VKJPG 01000	VKJP 01013	VKJP 01018	
VKJPG 01001	VKJP 01014	VKJP 01019	

For applicable specific rubber boot kits, please refer to SKF latest catalogue.

Install confidence  
[www.vsm.skf.com](http://www.vsm.skf.com)

VKJML 01001



© SKF is a registered trademark of the SKF Group.

© SKF Group 2015

The contents of this publication are the copyright of the publisher and may not be reproduced (even extracts) unless written permission is granted. Every care has been taken to ensure the accuracy of the information contained in this publication but no liability can be accepted for any loss or damage whether direct, indirect or consequential arising out of the use of the information contained herein.

February 2015