

SKF Technical Bulletin

VKBA 6699 – Noise or clearance before mounting



MERCEDES Sprinter, VW Crafter



Noise and Clearance will disappear after installation on the vehicle



| Car Make | OE Nb of the Complete knuckle |
|----------|--|
| Mercedes | A 906 33 02 420, A 906 33 02 520, A 906 33 03 420, A 906 33 03 520 |
| VW | 2E0 407 303P |

The bearing design for the SKF Kit VKBA 6699 conforms to interface dimensions on the OE surrounding components.

Proper fit to the knuckle is required for the bearing to achieve the correct preload for optimized life.

NOTE

- Before mounting when rotating the bearing by hand, you may experience noise or clearance
- After installing the bearing into the knuckle, noise and clearance will disappear (bearing is in preload)
- Follow the SKF mounting instruction MI-542022 and use proper tools for mounting and dismantling

VKBA 6699

