



Anziehvorschrift für Zylinderkopf		197.690	 Das Original
Tightening Instructions for Cylinder Head			
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		passend für / suitable for adaptable à / adaptable a GM	
			
Anziehen/ Tightening/ Serrage/ Apriete	M11 * Pos. 1-12: 30 Nm ➤ Pos. 1-12: 155°	M6 * Pos. 14-15: 7 Nm ➤ Pos. 14-15: 60° * Pos. 13: 7 Nm ➤ Pos. 13: 120°	
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ □ ● ➤	neue Zylinderkopf- schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor Ø: 96,4 mm; $\frac{1}{4}$: 0,65 mm Mot: LLR 3,7 ltr. Vortec 3700 Canyon, Bodystyle, Colorado, H3, i-370			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*197.690*	