

Anziehvorschrift für Zylinderkopf		240.650		passend für / suitable for adaptable à / adaptable a	VW / AUDI / SEAT / SKODA	Das Original
Tightening Instructions for Cylinder Head						
Instructions de serrage pour culasse						
Prescripciones de apriete para culatas						
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete				
10 4 2 6 8 7 5 1 3 9						
Anziehen/ Tightening/ Serrage/ Apriete	* ➤ ➤	30 Nm 65 Nm 90° 90°				
Zeichenerklärung / Explanations / Explication / Explicacion						
✱	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos		
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)		
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo		
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera		
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro		
Motortyp / Engine type / Type de moteur / Tipo de motor						
2,0l Bi-TDI EA288 176kW						
✱ 1,71mm / 3 Loch						
Mot: CUA						
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*240.650*			