

Anziehvorschrift für Zylinderkopf		245.630 passend für / suitable for adaptable à / adaptable a Audi	 Das Original																
Tightening Instructions for Cylinder Head																			
Instructions de serrage pour culasse																			
Prescripciones de apriete para culatas																			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete																	
 586.360 M 12x1,5x175		<table border="1"><tr><td>7</td><td>1</td><td>4</td><td>6</td></tr><tr><td>5</td><td>3</td><td>2</td><td>8</td></tr><tr><td>5</td><td>3</td><td>2</td><td>8</td></tr><tr><td>7</td><td>1</td><td>4</td><td>6</td></tr></table>		7	1	4	6	5	3	2	8	5	3	2	8	7	1	4	6
7	1	4	6																
5	3	2	8																
5	3	2	8																
7	1	4	6																
Anziehen/ Tightening/ Serrage/ Apriete		* 35 Nm 70 Nm 90° ➤ 90°																	
Zeichenerklärung / Explanations / Explication / Explicacion																			
✱	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos															
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)															
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo															
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera															
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro															
Motortyp / Engine type / Type de moteur / Tipo de motor 3,0 TDI 1,63 mm rechts/right Mot. CVUA, CVUB, CVUC, DEHA 235/240/250 KW (320/326/340 PS) A6, A6 allroad, A7, SQ5																			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*245.630*																