


Anziehvorschrift für Zylinderkopf		219.580	 Das Original	
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a VW / Audi / Skoda		
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
 527.770 M 12x206x1,75				
Anziehen/ Tightening/ Serrage/ Apriete		* 30 Nm ➤ 90 Nm ➤ 90° ➤ 90°		
Zeichenerklärung / Explanations / Explication / Explicacion				
✱	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
☐	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
1,4 TDI 3 Zyl. 2 Loch 1,63mm				
Mot: CUSA, CUSB, CUTA, CYZA, CYZB 55-77 KW (75-105 PS)				
Polo, Al, Fabia				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*219.580*	