



Anziehvorschrift für Zylinderkopf	650.420	 Das Original
Tightening Instructions for Cylinder Head		
Instructions de serrage pour culasse		
Prescripciones de apriete para culatas		
	passend für / suitable for adaptable à / adaptable a	FORD

Schraubenkopf / Head shape
Tête de vis / Cabeza de tornillo

Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete



642.570
M10x105x1,5



Anziehen/	*	10 Nm
Tightening/		40 Nm
Serrage/	□	- 45°
Apriete		30 Nm
	➤	90°
	➤	90°

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

Ø: 73mm ✎: 0,70mm

Mot:

M1CB, M1CA, M1DA, M1JA, M1JC, M1JE, M2DA
SFDA, M2GA, M2GB, P4JC, P4JD, P4JA, P4JB
SFCD, SFCC, SFCA, SFCA, SFJA, SFJB, SFJD
SFJC, XMJA, XMJB
1.0ltr. Ecoboost / Duratec

ElringKlinger AG, Max-Eyth-Str.2
72581 Dettingen / Erms. Tel. 07123/724 601

650.420