



<b>Anziehvorschrift für Zylinderkopf</b>	<b>867.700</b>	
<b>Tightening Instructions for Cylinder Head</b>		
<b>Instructions de serrage pour culasse</b>		
<b>Prescripciones de apriete para culatas</b>		
	passend für / suitable for adaptable à / adaptable a	<b>Renault, Nissan, Opel</b>
		Das Original

Schraubenkopf / Head shape      Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete  
Tête de vis / Cabeza de tornillo



577.070  
M12 x 1,5 x 135



Anziehen/	*	Pos 1-10: 5 Nm
Tightening/		Pos 1-10: 30 Nm
Serrage/	➤	Pos 1-10: 150° ±3°
Apriete	➤	Pos 1-10: 150° ±3

**Zeichenerklärung / Explanations / Explication / Explicacion**

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro

**Motortyp / Engine type / Type de moteur / Tipo de motor**

Mot: R9M

1.6 ltr 66-118 kW (90-160 PS)

Renault Scénic III, Grand Scénic, Megane III

Espace, Fluence

Nissan Qashqai, X-Trail

Opel Vivaro

ElringKlinger AG, Max-Eyth-Str.2  
72581 Dettingen / Erms. Tel. 07123/724 601

**\*867.700\***