


Anziehvorschrift für Zylinderkopf	987.043	 Das Original
Tightening Instructions for Cylinder Head		
Instructions de serrage pour culasse		
Prescripciones de apriete para culatas		
	passend für / suitable for adaptable à / adaptable a	Renault

Schraubenkopf / Head shape Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete
Tête de vis / Cabeza de tornillo



759.370
M 10 x 95/113



Anziehen/ Tightening/ Serrage/ Apriete	* 20 Nm	Pos. 7-10:
	▶ 100° ± 6°	□ 20 Nm + 100°±6°
	● 3 min	
	Pos. 1 und 2:	
	□ 20 Nm + 100°±6°	
	Pos. 3-6:	
	□ 20 Nm + 100°±6°	

Zeichenerklärung / Explanations / Explication / Explicacion

*	neue Zylinderkopfschrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
▶	Drehwinkel	torque angle	angle de serrage	ángulo de giro

Motortyp / Engine type / Type de moteur / Tipo de motor

Ø: 77 mm, $\frac{1}{2}$: 1,43 mm

Mot: E5F 710,716, E6J 700,701,706,712,
713,718,760, E7F 700,706, E7J 624
626,634,635,706,718,719,720,724,
726,728,742,745,754,780

R19,Clio,Kangoo,Megane,Rapid

ElringKlinger AG, Max-Eyth-Str.2
72581 Dettingen / Erms. Tel. 07123/724 601

987.043