

Montageanleitung | Installation Instruction | Notice de montage

Istruzioni di montaggio | Instrucciones de montaje

Instruções de montagem | Installationsanvisning | Montagehandleiding

de Innenraumfilter

en Cabin filter

fr Filtre d'habitacle

it Filtro abitacolo

es Filtro ventilación para interior

pt Filtro de cabine



sv Kupéfilter

nl Interieurfilter

6000161863



BOSCH



0 986 628 617

VW Touareg

01.03 -->

Audi Q7

03.06 -->

