

## Drucksteller Teilesatz für KE-Jetronic



### Merkmale

- Funktionsrelevantes Steuerteil der KE-Jetronic
- angebaut an Kraftstoffmengenteiler
- Funktionsweise wie Differenzdruckregler
- Zusatzfunktion wie Schubabschaltung und Drehzahlbegrenzung durch Reduktion der Kraftstoffzuführung zu den Einspritzventilen

### Kundennutzen

- Fertigung und Prüfung auf Originalanlagen
- Hohe Verfügbarkeit durch laufende Fertigung sichergestellt
- Lieferung als montagefertiger Teilesatz inklusive O-Ringen und Befestigungsschrauben

### Bestellnummer

**F 026 T03 ...**

kontinuierliche Programmerweiterung



**BOSCH**

## Pressure actuator sets (for KE-Jetronic)



### Features

- essential part of the KE-Jetronic
- fitted at the fuel distributor
- function like differential pressure regulator
- additional functions like overrun shut-off and motor speed limitation through reduction of injected fuel

### Customer Benefits

- production & testing with genuine assets
- high reliability through routine production
- delivery as kit ready for assembly, O-rings and mounting-screws

### Order Number

**Bosch F 026 T03 ...**

continuous extension of assortment



**BOSCH**

## Drucksteller Teilesatz für KE-Jetronic

Originalnummer		Bestellnummer	Marke
0 986 438 300	->	<b>F 026 T03 002</b>	Bentley, Ferrari, Mercedes-Benz
2 437 020 003	->	<b>F 026 T03 004</b>	Mercedes-Benz
2 437 020 005	->	<b>F 026 T03 005</b>	Audi, Ford, Nissan, Seat, VW
2 437 020 006	->	<b>F 026 T03 008</b>	Ford
2 437 020 008	->	<b>F 026 T03 009</b>	Ferrari
2 437 020 009	->	<b>F 026 T03 007</b>	Audi
3 437 010 027	->	<b>F 026 T03 004</b>	Mercedes-Benz
3 437 010 034	->	<b>F 026 T03 005</b>	Audi, Ford, Nissan, Seat, VW
3 437 010 040	->	<b>F 026 T03 002</b>	Bentley, Ferrari, Mercedes-Benz
3 437 010 041	->	<b>F 026 T03 008</b>	Ford
3 437 010 044	->	<b>F 026 T03 007</b>	Audi
F 026 T03 000	->	<b>F 026 T03 002</b>	Bentley, Ferrari, Mercedes-Benz
3 437 010 045	->	<b>F 026 T03 036</b>	Bentley



## Übersicht über alle relevanten Teilenummern

• 0986438300 ->	<b>F026T03002</b>	<b>A0000703962 0000703962</b>
• 2437020003 ->	<b>F026T03004</b>	
• 2437020005 ->	<b>F026T03005</b>	<b>034133482A</b>
• 2437020006 ->	<b>F026T03008</b>	
• 2437020008 ->	<b>F026T03009</b>	
• 2437020009 ->	<b>F026T03007</b>	
• 3437010027 ->	<b>F026T03004</b>	<b>A0000704062 0000704062</b>
• 3437010034 ->	<b>F026T03005</b>	<b>026133482</b>
• 3437010040 ->	<b>F026T03002</b>	<b>A0000703962 0000703962</b>
• 3437010041 ->	<b>F026T03008</b>	
• 3437010044 ->	<b>F026T03007</b>	<b>034133482</b>
• F026T03000 ->	<b>F026T03002</b>	
• 3437010045 ->	<b>F026T03036</b>	

