

FITTING INSTRUCTIONS

HOW TO ACCESS TO THE UPPER SHOCK ABSORBER MOUNTINGS

BMW 5 Series (E34) with fixed back seat



FI048EU



The upper mountings of the shock absorber assembly are not accessible via the trunk. Therefore it is necessary to remove the rear backseat.

- 1 Push-up the front of the rear bottom seat and put aside
- 2 Pull-up the head restraints.
To remove them, take off the plastic covers (turn the tightening bolts 1/4).
- 3 Remove the rear seatbelt retainers.
- 4 Push down the central seat and unscrew the 4 mountings of the back seat
- 5 Use a card (!!!) to protect the roof covering (C-style) while dismantling the back seat.
- 6 Pull the back seat hard to release it from the clamps
- 7 Take off the plastic cover:
The 3 upper mounting bolts are now accessible.

