

Einbauanleitung

Fitting instructions

Istruzioni di montaggio

Notice de montage

Instrucciones de montaje

Monteringsanvisning

CORTECO

Mitsubishi

Mitsubishi

Mitsubishi

Citroen

Citroen

Peugeot

Peugeot

ASX

Outlander

Lancer

C-Crosser

C4 Aircross

4007

4008

80000853

80000854

02.10 →

02.07 →

10.07 →

02.07 →

08.10 →

02.07 →

05.12 →



The Perfect Change.



10-20 min

