

Einbauanleitung

Fitting instructions

Istruzioni di montaggio

Notice de montage

Instrucciones de montaje

Monteringsanvisning

CORTECO

80001189

80001190



The Perfect Change.

Chrysler Dodge Avenger
 Chrysler Dodge Caliber
 Chrysler Dodge Journey
 Chrysler Jeep Compass
 Chrysler Jeep Patriot
 Fiat Freemont
 Lancia Flavia Cabrio

06.07 →
 06.06 →
 06.08 →
 08.06 →
 01.08 →
 08.11 →
 03.12 →

