

Solution

SWAG no. 50 93 0000



SWAG no. 50 93 0004



SWAG no. 50 92 9451



SWAG no. 50 93 0005



Unique in the aftermarket!

Only available from SWAG!

SWAG rear control arm including rubber mountings and mounting kit to fit Ford Focus and C-Max

Replacing the rear control arms of the Ford Focus and C-Max is often a demanding task. Due to heavy corrosion, the connection between the rubber mounting and the fastening bolt can only be released by breaking the bolts.

The nuts, tightly connected to the control arm by the manufacturer, can also only be removed forcefully.

Nuts and bolts must therefore be replaced. However, these control arms are supplied by the manufacturer as complete units without the frequently required fastenings.

**No more time-consuming re-ordering of individual components:
With this SWAG repair kit, you get everything you need without delay!**

SWAG 50 93 0000

bottom rear control arm including rubber mountings and fastening kit

SWAG 50 93 0004

top rear control arm including rubber mountings and fastening kit

Of course, all components are also available individually from SWAG.

**Ask your SWAG distributor about SWAG replacement parts!
You can also find all replacement parts on www.swag.de**