

Part identification of the steering gearbox – Volvo XC90 I



Observe the following when converting a Koyo/SMI to a ZF steering gearbox:

Due to possible differences on the input shaft of the steering, replace the steering spindle between the steering gearbox and the steering column with the universal joint.

The following table and the figures show whether the universal joint is required.

Year of manufacture	TRW part number	Version	OE number for universal joint
2003 – 2004	JRP1042	speed-dependent	30741476
	JRP1004	standard	
	JRP933		
2005 – 2014	JRP1061	speed-dependent	30741476
	JRP1062	standard	



Old joint (steering spindle) without recess



New universal joint with recess