## 🖻 febi 27730, 27111

Now available in the febi range: Universal CV boot repair kits for cars and universal CV boot repair kits for LCVs and SUVs!





febi 27730

febi 27111

## Just two parts for nearly the whole vehicle parc!

CV boot kit for cars febi no. 27730 with clamps and 90g of grease febi no. 02582

CV boot kit for LCVs / SUVs febi no. 27111 with clamps and 180g grease febi no. 02582

The CV boots come with removable collars (five and six respectively) and, therefore, cover nearly all common car and LCV / SUV models.



These universal CV boots can be fitted on both the inner and outer CV joints. By using the correct tool, you can stretch the boots up to 10cm in diameter which allows quick and easy fitting. It is not necessary to completely remove the prop shaft and drive shaft!

This considerably reduces the fitting time and saves the customer money.

For quick and easy tensioning and cutting of the CV boot clamps we recommend the use of the KLANN clamp tools KL-0121-85 and KL-0121-86.

For more technical information please visit: partsfinder.bilsteingroup.com



EN

KL-0121-85





