

Technical Information TI14-007

DTE-3007

DKW-3002 / DKW-3003 / DKW-3004


OEM References


2441027000

2441027250

MODALITY OF ASSEMBLING AND TENSION-SETTING OF THE TENSIONER

- Verify that timing marks A and B are lined up
- Assemble the new tensioner and the new idler
- Ensure that the tensioner is correctly positioned
- Assemble the timing belt anti-clockwise, starting from the crankshaft pinion
- Slacken the bolt "a" (Fig. 1)
- Rotate the crankshaft 2 revolutions clockwise
- Verify that the timing marks A and B are lined up
- Block the bolt "a" (10-12 Nm)
- Unthread the hinge "b" (Fig. 1) from the base plate of the tensioner
- Re-install other removed parts
- Block the bolts of the cranks-haft pulley (50-55 Nm)







Need more info? Check our website: www.kavoparts.com