

STEP 1

SELECT YOUR WIPER
ARM CONNECTION

STEP 2

FIND THE MATCHING
ADAPTER

STEP 3

INSTALL YOUR FLAT WIPER BLADE
FOLLOWING THE INSTRUCTIONS BELOW

U-Hook 9X3mm,9X4mm



U



Side Pin 5X22mm



A



Side Pin 5X17mm (P & H Arm)



A



Pinch Tab 15mm (I & L Arm)



B



Pinch Tab 15mm (I & L Arm)



B



Push Button 19mm (PTB Arm)



C



Bayonet 9X4mm



D



Screw Arm



E



Screw Arm



E



Claw Arm 6mm



F



Push Button 16mm (PTB Arm)



G



Special Hook 16mm



H



Special Hook 12mm



M



Special Hook 15.5mm



R



Push Button 15.5mm



Y

