



Anziehvorschrift für Zylinderkopf		818.276		
Tightening Instructions for Cylinder Head				
Instructions de serrage pour culasse				
Prescripciones de apriete para culatas				
passend für / suitable for adaptable à / adaptable a		Nissan	Das Original	
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo				
		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete		
710.080 M 10				
Anziehen/ Tightening/ Serrage/ Apriete	E 13 * 39 - 44 Nm 69 - 74 Nm ★ 15 min 69 - 74 Nm	E 13 S, E 15 S * E 16, E 16 i 29 Nm 69 Nm □ 29 Nm 69 - 74 Nm		
Zeichenerklärung / Explanations / Explication / Explicacion				
★	neue Zylinderkopf- schrauben verwenden	use new cylinder head bolts	utiliser des vis neuves	emplar tornillos nuevos
★	Warmlauf (80°C)	warm up time (80°C)	chauffage (80°C)	calentamiento (80°C)
□	Schrauben einzeln lösen und wieder anziehen	loosen and tighten each bolt	deserrer et serrer vis par vis	aflojar y apretar tornillo a tornillo
●	Setzzeit	relaxation time	durée de tassement	tiempo de espera
➤	Drehwinkel	torque angle	angle de serrage	ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor				
Ø: 77,5 mm				
Mot: E13, E15S, E16i, E16S				
1,3 ltr.-1,6 ltr. 44-77 kW (60-105 PS)				
Cherry, Prairie, Sunny I-II				
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601			*818.276*	