



Multi V-belt Elast + Tool


6PK1019 ELAST T1 (5PK690 ELAST)




1




2




3




4




5




6



7



8




9




Multi V-belt Elast + Tool


6PK1019 ELAST T1 (5PK690 ELAST)




10




11




12




13




14




15



16



17



18



Data, instructions and other technical information available from the PIC at www.contitech.de/pic or simply scan the QR code.



The content of this publication is not legally binding and is provided as information only. The trademarks displayed in this publication are the property of Continental AG and/or its affiliates. Copyright © 2015 ContiTech AG. All rights reserved. For complete information go to: www.contitech.de/disc_en



ContiTech Antriebssysteme GmbH
 Hannover · Germany
 Tech. Hotline +49 (0)511 938-5178
aam@ptg.contitech.de · www.contitech.de/aam

ContiTech