

Opel Meriva

Opel Meriva

- Ⓓ Wechselintervall alle ...
- ⒼⒷ Replacement interval ...
- Ⓘ Sostituzione dopo ...
- Ⓕ Intervalle de replacement ...
- Ⓔ Intervalle de cambio ...
- ⒹⒻ Vervanging elke ...

15.000 km /

10.000 mi

- Ⓓ ... oder nach 1 Jahr
- ⒼⒷ ... or after 1 year
- Ⓘ ... or dopo 1 anno
- Ⓕ ... ou 1 fois par an
- Ⓔ ... o después de 1 ano
- ⒹⒻ ... of 1 keer per jaar

micronAir[®]

Opel Meriva 03 →

21652995 / CC1113 / MC 639
21652994 / CP1113 / MP 139

Einbauanleitung

Innenraumfilter

Fitting instructions

Cabin air filter

Istruzioni di montaggio

Filtro abitacolo

Notice de montage

Filtre d'habitacle

Instrucciones de montaje

Filtro de habitáculo

Inbouwhandleiding

Interieurfilter

www.micronair.com

© by Freudenberg Vliesstoffe KG 12/2002

