INSTALLATION INSTRUCTIONS





<u>Fig.1</u>

1. Replace the gasket and point the filter towards the cap as shown in fig.1.





Fig.3

3. Pull the retaining clip.



<u>Fig.2</u>

2. Push the filter firmly until it clicks.
Oil the new gasket.



4. Screw the cap with the filter on the housing using 40Nm torque. Push back the retaining clip.



MAHLE OX 1293D