




## PSP2365

The supplied pump is presented with a 16 mm inlet pipe. If your car is using a 18 mm hose, please follow the next instructions:

### STEP 1:

To see what hose diameter are you needing, measure the pipe of the old power steering pump.




OLD PUMP - 18mm PIPE



NEW PUMP - 16mm PIPE

### STEP 2:

Remove and swap the pipe. It is recommended to use the new o-ring.



BGA products are to be replaced by an experienced automotive installer. This information is to be used as reference only. Always seek manufacturer specification.

