

# Technical Bulletin.

## Brake Pads Fitted with wire clamps on the back plate.

Some Brake Pads are fitted with wire clamps on the back plate.

The inner (piston side) pads are fitted with wire clamps. These must be correctly seated into the external groove cut into the piston. This device ensures that the pad remains in contact with the piston at all times and is essential for the correct operation of the caliper.

Failure to observe this will result in serious brake noise and damage to the caliper.

**Pads affected include:**      **PAD1195**  
   **PAD1287**  
   **PAD1328**

