

INSTALLATION MANUAL

SK-3012
Arnott New Rear Shock
Mercedes-Benz E-Class/CLS-Class
(W211/W219, w/ADS, Sedans Only)



Engineered to Ride, Built to Last®

CONGRATULATIONS ON YOUR PURCHASE OF AN ARNOTT® SUSPENSION PRODUCT

WE AT ARNOTT LLC ARE PROUD TO OFFER A HIGH QUALITY PRODUCT WITH ALL THE TECHNICAL SUPPORT YOU NEED. THANK YOU FOR YOUR CONFIDENCE IN US AND OUR PRODUCT.

Proper installation is essential to experience and appreciate the benefits of this system. Please take a moment to review these installation instructions before you begin to install these components on your vehicle. The removal and installation of air suspension products should only be performed by a fully qualified and certified automotive professional.

It is equally important to be aware of all necessary safety measures while installing your new Air Suspension System. This includes proper lifting and immobilizing of the vehicle and isolation of any stored energy to prevent personal injury or property damage.

GENERAL INFORMATION

Reading this manual signifies your agreement to the terms of the general release, waiver of liability, and hold harmless agreement, the full text of which is available at www.arnottinc.com and www.arnotteurope.com.



WARNING:

The air suspension system is under pressure (up to 10 bar, or 150 lbf/in). Verify pressure has been relieved and disconnect power to the air suspension system prior to disassembly. Do not allow dirt or grease to enter the system. Always wear standard hand, ear, and eye protection when servicing the air suspension system.

- Not to be stored below 5°F (-15°C) and above 122°F (50°C).
- Avoid damage to air lines and cables.
- Removal and installation is only to be performed by fully qualified personnel.
- Use car manufacturer's diagnostic software.

CAUTION:

Damage to the vehicle and air suspension system can be incurred if work is carried out in a manner other than specified in the instructions or in a different sequence.

To avoid the possibility of short circuits while working with electric components consult your owner's manual on how to disconnect your battery.

Consult your vehicle owner's manual, service manual, or car dealer for the correct jacking points on your vehicle and for additional care, safety and maintenance instructions. Under no circumstances should any work be completed underneath the vehicle if it is not adequately supported, as serious injuries and death can occur.

For vehicles with a "Closed Air Supply System," replacement of components requires proper adherence to procedures set forth within OE servicing literature. Failure to comply with the OE prescribed procedures can result in component damage and/or failure.

REAR SHOCK REMOVAL

- 1. Set steering to straight.
- 2. Raise vehicle.
- 3. Remove applicable rear wheel and wheel well liner. (Figure 1)



FIGURE 1

4. Using the DAS-STAR system, electronically deflate the rear air spring. (Figure 2)



FIGURE 2

5. Disconnect the top two electrical connectors and unroute the wires. (Figure 3)



FIGURE 3

6. Loosen and remove the strut rod bolt/nut. (Figures 4, 5)







FIGURE 5

7. Loosen, but do not remove the air spring's bottom mount bolt/nut. (Figure 6)



FIGURE 6

8. Loosen and remove the bottom mount bolt/nut from the damper. (Figure 7)



FIGURE 7

9. Removal applicable trunk liner.

10. In the trunk, loosen and remove the top damper nut. Save the washer and rubber bushing for re-use. (Figure 8)



FIGURE 8

11. Compress the damper and remove from vehicle. (Figures 9, 10)








FIGURE 10

12. Removal complete.

REAR SHOCK INSTALLATION



WARNING:

Tighten all nuts and bolts to manufacturer's specifications during the installation process.

1. Remove the top nut from the damper. Do not discard the nut. (Figure 11)



FIGURE 11

2. Install the damper into the vehicle. (Figure 12)



FIGURE 12

3. Reinstall previously removed bushing and washer onto the top of the damper tennon. (Figures 13, 14)





FIGURE 13 FIGURE 14

4. Reinstall the provided top nut onto the damper and tighten to manufacturer's specifications. (Figure 15)



FIGURE 15

5. Reinstall the damper's bottom mount bolt/nut and tighten to manufacturer's specifications. (Figure 16)



FIGURE 16

6. Tighten the air spring's bottom mount bolt to manufacturer's specifications. (Figure 17)



FIGURE 17

7. Reinstall the strut rod bolt/nut and tighten to manufacturer's specifications. (Figure 18)



FIGURE 18

8. Reroute the electrical connector wires back through, fastening them into their respective clips. (Figures 19, 20, 21)








FIGURE 21

9. Reinstall the two electrical connectors into the vehicle. (Figures 22, 23)





FIGURE 22 FIGURE 23

10. Fasten the electrical wires into place along the wiring guide. (Figure 24)



FIGURE 24

- 11. Reinstall wheel well and trunk liners.
- 12. Reinstall the wheel.
- 13. Lower the vehicle.
- 14. Installation complete.



Arnott US Business Office:

www.arnottinc.com

100 Sea Ray Drive Merritt Island, FL 32953

Call: 800.251.8993

321.868.3016

Fax: 321.868.3703

Email: techassistance@arnottinc.com

Arnott Europe Business Office:

www.arnotteurope.com

Industrieweg 19 5145 PD, Waalwijk (NL)

NL Phone: +31 73 7850 580

DE Phone: +31 85 2087 438

UK Phone: +44 203 3186 124

BE Phone: +32 258 846 90

ES Phone: +34 91 901 10 56

FR Phone: +32 78 48 46 93

Email: info@arnotteurope.com



Air Springs



Struts



Shocks



Compressors



Dryers



Coil Spring Conversion Kits



Valve Blocks



Ride Height Sensors